

## Breakpoint Super-Chlorination Worksheet

**Step One: Determine the amount of Combined Chlorine** **(CC = TC – FC)**

**Step Two: Calculate the Breakpoint Chlorination (BPC) amount** **(CC x 10)**

**Step Three: Determine the desired change amount (DC)** **(BPC – FC)**

	Total Chlorine		Free Chlorine		Combine Chlorine
<b>Step One</b>		-		=	
<b>Step Two</b>	<b>Multiply by 10</b>				
<b>Step Three</b>	<b>Subtract the Free Chlorine</b>				<b>-</b>
<b>Use this number in the C-1 (desired change) blank in the Chemical Adjustment Worksheet</b>					

Chemical Adjustment Worksheet					
A – Amount (from label or other source)	B – BIG		C – Change		Total
	<u>B-1</u> Actual Gals		<u>C-1</u> Actual Chg		
		Divide		Divide	
	<u>B-2</u> Label Gals		<u>C-2</u> Label Chg		
	Times		Times		
				Divide ? <b>oz?</b> (16) or <b>fl. oz?</b> (128)	
				Final Answer	